


FMC



JOSAM




Parts Reference

FMC/Josam Truck Aligner

The World Leader in Truck Frame Service Equipment

Josam Standard Measuring Kit - 85919




Ref #	Qty	Part #	Description	Josam Ref. Number
1	2	85920	GAUGE-CENTERING, SELF	JT120
2	8	85921	HANGER	JT121
3	2	85922	EXTENSION-RIGHT	JT122
4	2	85923	EXTENSION-LEFT	JT123
5	2	85924	TARGET-FRONT	JT130
*	2	85925	TARGET-REAR	JT131
6	2	85926	ADAPTER-WHEEL	JT140
7	1	85927	EXTENSION-MAX TURN	JT160
8	1	85928	ADAPTER-SEMI & FULL TRAILER	JT180
9	1	85929	LEVEL-SPIRIT	JT188
10	2	85937	HANGERS-MAGNET	JT170
11	1	85917	MEASURING HEAD	JT101
12	1	85911	HANDHELD COMPUTER DISPLAY	JT100
13	2	85966	FRICTION PLATES	AM268
*	1	85912	INTERCONNECT CABLE (13ft)	JT102
*	1	85918	INTERCONNECT CABLE (23ft)	JT103
*	1	85930	ELECTRONIC LEVEL	JT108


* Not Shown

NOTE: Some accessories listed above may be optional

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	85569	Keyboard
*	85718	Keyboard with Decal
*	85594	Cable, keyboard jumper assy. (UL&CSA)
*	86134	Keyboard cover Antec Keyboard
*	85690	Keyboard decal kit
2	85567	Remote control
*	1122063	Battery for Remote
3	86018	Printer kit 115V
*	84336	Printer 115V
4	83055	Printer interface cable to PC
*	83049	Printer paper
*	86162	Cable Assy., Printer jumper
*	83787	Seikosha printer ribbon
5	85378	CD Software - Truck

* Not Shown






Upper Console

Upper Console Assembly



Ref	Part				
<u>No.</u>	<u>No.</u>	<u>Description</u>	<u>No.</u>	<u>No.</u>	<u>Description</u>
1	85500	Bezel front	26	1181298	Nut, Keps #8-32
2	85509	Panel side (2 used)			(14 used)
	85509	Panel side (2 used)	27	61746	Washer, flat, black oxide
3	85510	Door, rear access			(9 used)
	86004	Door, rear access	28	1101540	Nut, Keps 1/4-20 (12 used)
4	85511	Panel, top	29	1107381	Washer, flat 1/4-20 (12 used)
	86005	Panel, top	30	1101884	Screw self tap #8-32x3/4
5	85512	Bracket, PC support bottom			(5 used)
6	85513	Bracket, PC support top	31	1101538	Washer, lock #8
7	85545	Bracket, PC support rear			(6 used)
8	85514	Bracket, CRT support	32	83558	Screw ground, 8-32
9	85515	Shelf keyboard			(3 used)
	86008	Shelf keyboard	33	85638	Assembly, SpeakerPhonocable
10	85619	Panel, shield	34	85564	Crt-19" color open frame
	86067	Panel, shield	35	1101753	Nut, Tinnerman 8-32 (2 used)
11	85516	Magnet Snap in (2 used)	36	85554	Interconnect box assembly
12	85517	Plate Striker (2 used)	37	85537	Assembly, remote receiver
13	85518	Latch, vise action (2 used)	38	85539	Optical filter
14	85519	Plug, dome (4 used)	39	64383	Tie wrap
15	85520	Card guide (4 used)	40	999692	Flex grommet
16	1107381	1/4, Washer (29 used)	41	1110594	Screw 4-40x3/16" (2 used)
17	122057	Screw self-tap 6-32	42	85508	Door front Bezel
		(56 used)	43	85686	GND wire top panel to back
18	1122058	1/4-20 Nut, self clinch			panel 12"
19	1102723	1/4-20x1.0 Screw thumb	44	85687	Ground Wire 28" (2 Used)
20	1122059	Retaining ring (2 used)	45	1122061	Plug, hole
21	1101800	Nut, 1/4-20, Tinnerman	46	85664	Bumper front bezel
		(5 used)	47	84163	Tie wrap
22	1100805	Screw, 1/4-20x3/4"	48	85661	Cable assy. power jack main
		(4 used)	*	85716	AC Power cord (115V)
23	1100241	Washer, lock (4 used)	*	85717	AC Power cord (230V)
24	1100254	Washer, flat (4 used)			
25	1101883	Screw, self tap #8-32 x3/8"			
		(4 used)			
Ref	Part		*	NOT SHOWN	

Computer Assembly



Computer Assembly


Ref	Part	
<u>No.</u>	<u>No.</u>	<u>Description</u>
1	85530	Case assy. mini-tower w/power supply
2	85529	Power supply 200 watt
3	85526EXO	Motherboard, 486-33
4	85521	256k X 9simmm (1 Meg. each)
5	85528	Controller VGA
6	85527SVC	IDE Controller card
7	86128	Drive kit, CD ROM (w/ 86367 CD)
8	1101760	Nut, keps #6-32
9	85501	Controller Assy. Head Interface
10	85549	Bracket, 12VDC connector
11	1101532	Screw, #6-32x3/8" Pan head
12	85536	Cable assy, PC power supply
13	85663	Cable assy, PC speaker/HIB
14	1101594	Terminal, female 18-22 AWG wire
15	1101616	Terminal, #8 ring 16-22 AWG wire
16	84121	Cable Audio
17	86016	Drive, Floppy 1.44MB 3.5"
18	85793	Drive, Hard - IDE
19	1122049	Screw, self tap #6-32x3/8"
20	85737	Power Splitter 3.5" floppy
	85639	Power cord (115V)
	85655	Power cord (220V)



Base/Pedestal Assembly - 85945

Ref	Part	
<u>No.</u>	<u>No.</u>	<u>Description</u>
1	63590	Caster (4 Used)
2	85578	Rail weldment side (2 Used)
3	85579	Rail, RH cross (2 Used)
4	85580	Rail,center cross (2 Used)
5	85581	Rail, LH cross (2 Used)
6	85583	Cover, pedestal (2 Used)
7	85584	Extension Pedestal large
8	86006	Extension, pedestal-V6
9	85618	Spacer rails (12 Used)
10	85659	Spacer,pedestal (2 Used)
11	1122050	1/4-20x 1 1/2 screw self tap (12 Used)
12	1100044	5/16-18X3/4, Screw -HHC
13	1100242	5/16-18 lock washer (16 Used)
14	1107382	5/16 flat washer (16 Used)
15	1101540	1/4-20, keps nut (54 Used)
16	1107381	1/4 flat washer (12 Used)
17	1122075	1/4-20 X 3/4, screw-HHC (28 Used)
18	1101882	1/4-20X1 1/2 Screw -Pan head (2 Used)
19	85596	Decal Visualiner Series
20	85693	Decal JohnBean
*	86594	SV8 Lower Cabinet Decal
*	86595	SV8 Lower Cabinet Decal
21	85672	Decal Red dot (4 Used)
22	85585	Lower Cabinet Assy. (Complete with doors and slide drawer.)

Console Cabinet Assembly




85352a1.000

Console Cabinet Assembly

Ref		Part	
<u>No.</u>	<u>QTY</u>	<u>No.</u>	<u>Description</u>
2	2	85340	Bracket, Storage Hinge
3	4	85342	Plate, Storage Lock
4	2	85343	Plate, Storage Support
5	2	85345	Storage Support Channel
6	4	85346	Protective Mat, Large
7	2	85347	Protective Mat, Small
8	1	85348	Cross Rail, Weldment
9	2	85349	Support Rail, Weldment
10	4	1122238	Washer, Hardened, 2.25 OD, 1.16 ID
11	4	1122240	Washer, Hardened, 1.38 OD, .66 ID
12	4	1122241	Nut, Steel Flanged, 5/8 - 11
13	4	1112340	Screw, SHC, 5/8 - 11 x 4.0
14	16	1101988	Screw, Self tap, Hex hd wash, 1/4 - 20 x 3/4
15	2	1102372	Screw, SHC, 3/8 - 16 x 4.0
16	2	1122120	Washer, Flat, 3/8 (Black
17	-	1122246	Trim Rubber
18	2	1122248	Grommet - 1.31 OD, .75 ID
19	20	61746	Washer, Flat, #10 Black
20	4	1122261	Screw, BHC, #6 - 32 x 1.5
21	4	110176	Nut, KEPS, #6 - 32
22	6	1101467	Screw, BHC, #10 - 24 x 5
23	6	1101479	Nut - KEPS, #10 - 24
24	2	1177619	Screw - BHC, 1/4 - 20 x .5
25	2	1101609	Nut - ESNA, 1/4 - 20
26	4	1122243	Rubber Bumper
27	4	1101740	Screw, BHC #8 - 32 x .25
28	2	85470	Holder - Gauge Storage
29	2	85488	Plate, Holder Support
30	8	1122271	Hole Plug, .312 Diameter hole.
31	4	1122009	Screw, BHC, 1/4 - 20 x 1 1/2
32	4	1122269	Washer, Flat, 1/4 Black
33	4	1122270	Plug, Sq, 1.0 x 1.0
34	4	1101540	Nut, KEPS, 1/4 - 20

Interconnect Box Assembly- 85934



Interconnect Box Assembly

Ref No.	QTY	Part No.	Description
1	1	85704	Label - Power Strip
2	4	111631	Label - Frame or Chasis Terminal
3	4	85547	Fuseholder
4	1	85657	Relay - DPDT
5	1	85665	Panel Connector
6	1	85667	Panel Top
7	1	86986	Panel Bottom
8	1	85669	Panel Divider
9	2	85670	Strain Relief Clamp
10	14	1101883	Screw - Self Tap, 8 - 32 x 3/8
11	4	83558	Screw - Ground, 8 - 32
12	2	1122049	Screw - Self Tap, 6 - 32
13	12	1101760	Nut - KEPS, 6 - 32
14	8	1181298	Nut - KEPS, 8 - 32
15	8	1101884	Screw, Self Tap, 8 - 32 x 3/4
16	4	85535	Terminal Block
17	1	85661	Cable Assembly, Power jack/main
18	1	85662	Cable Assembly, Main Fuse/Relay
19	1	85709	Wire, term blocks/relay (black)
20	1	85708	Wire, term blocks/relay (white)
21	1	85706	Wire, CPU/Main Fuse (white)
22	1	85707	Wire, CPU/Main Fuse (black)
23	1	85941	Cable Assembly, HIB/Interconnect box
24	10	1122051	PEM Stud, 6 - 32 x 1/2
25	1	85940	Label, Fuse Holder - Truck
26	4	1101594	Insulated Terminal
27	1	74208	Fuse - 3A
28	2	74120	Fuse - 8A - Slowblow
31	1	86465	Warning Label, Shock Hazard
32	1	85831	Cable - Head, Truck Adapter
33	4	1101888	Screw - PHMS, #4 - 40 x 3/8
34	4	1109762	Nut - HEX, #4 - 40
35	1	74344	Fuse - 1A Fastblow
36	1	85939	Switch Assembly, Reset, Adapter
37	1	85887	PCB Assembly, Truck Adapter
38	6	83642	Washer - .25 OD x .172 ID x .187 LG
39	1	85703	Label - Caution, 230V
40	1	85947	Label - Warning, Live Terminals
41	1	85948	Label - AC, 240V